




# DHSH – Double Hung Solar Heating Installation Manuel

1)Place the panel in the upper section of the southern facing double hung window. Place the bottom of the DHSH in first so that the panel is on slight angle.



2)On the top side of the DSHS, slide in both pins on each sides at the same time and fit the panel into the widow, release the pins back out so they expand into the window channel securing the panel.



**Note:** If you can't place the panel pines safely in the window channel, contact us and we will send you an alternative securing device.

3)Plug the adapter to the 120v power outlet and into the panel.





4) Using the ON switch, check the panel to ensure the Left Side Inlet is pulling the air in and the Right Side Outlet is pushing the air out. After checking turn the DSHS back off.

Use the auto switch to run the panel automatically every time that the sun is out. The panel will start automatically and blow hot air into the room.

You will be able to see the air temperature in the digital display.



5) You can cover the upper part of the panel (above the inlet and outlet) with anything you like, such as drapes or curtains.

#### Warnings:

- Make sure the panel is securely in the window, checking the pins are in the window channel.
- Make sure the inlet and the out let are free from any obstructions.
- Make sure the electric wire is out of the way so it can not accidentally be pulled or tripped over, potentially causing the DSHS to fall.
- Remove the panel during the summer.

If you have any questions, please call U.S. Solar Heating at 1-866-537-8232  
(Monday-Friday 9-5 CST).